



Window Touch Up Procedure

Royal Bond Spectra Coat & Pro Lux Finishes

- Ensure the affected area is clean and free of any loose paint or debris.
- Use the brush in the touch up bottle to apply a small amount of paint to the area. Do not over apply or blemished area may be magnified.
- Wait 15 minutes for the first coat to dry.
- Apply and blend a second coat if needed.





Chip / Scratch



Chip /Scratch after touch-up.